

## D-BLOCK ASSEMBLY INSTRUCTIONS



### COMPONENTS PARTS



Secure bracket to D-Block using retaining nut, take the VITAL flow corrector & insert the flow corrector in to the elbow as shown above



Apply a small amount of thread sealer to the elbow male thread and screw down until the flange of the corrector is 'nipped' and sealed in to position. Ideally the elbow inlet should be positioned centrally to the D-Block exits to produce optimum distribution.